



## **WEIYE OPTOELECTRONIC TECHNOLOGY CO., LIMITED**

Address: Building 5, Zhong Liang Industrial, FuAn Rd, Dayangtian, Fuyong, BaoAn,  
Shenzhen, China. 518103.

Tel: 86-755-27370606 Fax:86-755-27370606

Email: [info@aku-led.com](mailto:info@aku-led.com) / Website: <http://www.lhwyled.com/>

### **Installation Guide:**

1. Before starting the installation please ensure to disconnect the power;
2. After turning on the switch, temperature of the lamp rising gradually, when the lamp is lighting or not completely cooled, pls do not touch the lamp with hand;
3. If should change lamp, please cut off the power firstly,then change the lamp after it has been cooled enough(for details see the direction of changing lamps );
4. The lamp must not exceed the specified wattage;
5. When protective glasses are damaged,must change new one, do not use without protective glass;
6. Please do not look at the lighting lamp directly;
7. Be sure to connect ground lead;

### **Direction of changing lamps:**

1. Turn off the power;
2. Open lamp access cover;
3. Twist out lamp slightly;

4. Do not touch the lamp with bare hand;
5. When installing the lamp, pls twist lamp in socket carefully;
6. Before turning on the power, replace lamp access cover;